POSTPROCESS DETERGENT RENUMBERING KEY

Material - Technology - Process

PLM = Polymer MTL = Metal AUX = Auxiliary

100 series = PolyJet

200 series = FDM

300 series = MJF

400 series = Resins

500 series = STEP

ess
DEMI 200 DEMI 400 DEMI 800
DECI BASE
RADOR LEVO NITOR
DECI DUO

OLD		NEW	
PG1	=	PLM-101-SUB	PolyJet
PG2	=	PLM-201-SUB	FDM
PG2.1	=	PLM-202-SUB	LDIVI
PG1.1	=	PLM-401-SUB	
PG1.2	=	PLM-402-SUB	Resin
PG1.3	=	PLM-403-SUB	
PG1C Part A	=	PLM-101-SPRAY]
PG1C Part B	=	PLM-102-SPRAY	PolyJet
PG2C Part A	=	PLM-201-SPRAY	
PG2C Part B	=	PLM-202-SPRAY	FDM
PG2C Part C	=	PLM-203-SPRAY	
PG1.1C Part A	=	PLM-401-SPRAY	Resin
PG1.1C Part B	=	PLM-402-SPRAY] Resili
PG2.2C DEV Part A	=	PLM-501-SPRAY	STEP
PG2.2C DEV Part B	=	PLM-502-SPRAY	JSTEP
PG3	=	PLM-001-SURF	
PG5	=	PLM-001-DUO	
PG7.1	=	AUX-001-DEFOAM	
PG7.2	=	AUX-002-DEFOAM	
PG7.3	=	AUX-003-DEFOAM	
Duo Clean	=	AUX-001-CLEAN	
PGN	=	AUX-001-NEU	



Auxiliary

Supple-

mental